

VIEW LOOKING FORWARD AT B'LKH'D. #20

NOSE WHEEL DOOR OPERATING LINKAGE SHOWN WITH NOSE WHEEL DOORS CLOSED.

NOTE:-
LOCATE SEQUENCE VALVE ON 28F6611 BRACKET SO THAT 28F6610 BOLT MOVES SEQUENCE VALVE PLUNGER APPROX. 3/8", WITH ADJUSTING KNOB ON SEQUENCE VALVE IN NEUTRAL POSITION, WHEN DOORS ARE FULLY CLOSED. SEQUENCE VALVE HOWEVER SHOULD NOT BE LOCATED UNTIL ADJUSTMENT ON 28B5573 ARM & DOOR LINKAGE IS DETERMINED.

LET.	ALTERATION	DATE	BY	LET.	ALTERATION	DATE	BY
A	Changed Parts List & Dimensions 28F6501 Seq. Valve & Bracket Location	12-3-43	[illegible]				

PART NO.	STOCK	MATERIAL	SPEC.	LT. NO. DIG.	LT. NO. DIG.	LT. NO. DIG.	LT. NO. DIG.	LT. NO. DIG.
				-0	-2	-3	-4	-5
AN4-D10A				2				
AN4-D10A				3				
28F6501				1				

PARTS LIST PER ASSY.

NAME INSTALL. - SEQ. VALVE NOSE WHEEL DOOR LOCK-HYD. SYS.

CONSOLIDATED AIRCRAFT CORP. San Diego, Calif.

SIZE J — 28F6612

H 383